




Quick setup guide




1




2



3



4



5

Please check and identify all supplied accessories



1. Foldable box*



2. Nut



3. Power adapter 5B / 1A




4. Cable USB A / Type C



5. Quick setup guide



*The nut, USB cable and power adapter are inside the folded box



Fold the holder as shown on the fig. 1 and clip velcro fasteners.

Insert the paper target into dedicated slits inside the box. Supports target size 170 x 170 mm.

Mount the holder on a wall or a photo tripod and connect it to the power adapter.